




**Work Supports**


contact by spring force or air pressure,  
single acting, max. operating pressure 500 bar





192X01



192X02



192X03



**Application**

Hydraulic work supports are used to provide a self-adjusting rest for the workpiece during the machining operations. They compensate the workpiece surface irregularities, also deflection and vibration under machining loads.

**Installation**

The universal block cylinder shape allows vertical and horizontal mounting, with oil feed via normal pipe connection or by manifold mounting direct to the fixture through drilled channels in the fixture body.

**Function**

Hydraulic locking is made together with hydraulic clamping of the workpiece, or independently. The support plunger is provided with female thread to enable the use of threaded pieces for height adjustment.


**There are three variations of plunger actuation:**

- 1. Spring advanced;** plunger extended in off-position
  - 2. Air pressure advanced;** without spring return
  - 3. Air pressure advanced;** with spring return
- The pneumatically-actuated plunger allows precise setting of the plunger contact force by means of a pressure reducing valve. If a danger exists of sucking fluids through the pneumatic port, on the spring-advanced unit, a vent hose should be connected.

**Important notes**

Work supports are not suitable to compensate side loads.  
Operating conditions, tolerances and other data see data sheet A 0.100.  
It is absolutely necessary to follow the instructions for venting of the spring area on data sheet G 0.110.

**Admissible load F as function of the operating pressure p**



Plunger Ø D	[mm]	16	20	35
Stroke	[mm]	6	8	10
Support force at 500 bar	[kN]	7	12.5	28
Spring force min.	[N]	8	13.5	19.2
Spring force max.	[N]	10	17	24
Plunger contact force at 1 bar air pressure (deduct spring force if necessary)	[N]	20.1	31.4	96.2
Recom. min. oil pressure	[bar]	100	100	100
a	[mm]	60	65	85
b	[mm]	35	45	63
c	[mm]	40	50	63
d	[mm]	22	30	40
e	[mm]	56	64	79
f	[mm]	12	15	20
f1	[mm]	6	7	10
g	[mm]	26	36	39
h	[mm]	36	43	52
i	[mm]	7	10	12
k	[mm]	12.5	11.5	20.5
l	[mm]	17.5	25.5	39.5
m	[mm]	8.5	8	8
n	[mm]	38	22	25
o	[mm]	14.5	19	25
p	[mm]	5	7	11
Ø r	[mm]	M 10	M 12	M 16
s	[mm]	14	14	21
Ø t	[mm]	6.5	8.5	10.5
u	[mm]	6	8	10
SW	[mm]	13	17	27
Weight	[kg]	0.8	1.2	2.6
<b>Part no.</b>				
<b>Extended by:</b> Spring force		<b>1921 101</b>	<b>1923001</b>	<b>1925001</b>
Air pressure		<b>1921 102</b>	<b>1923002</b>	<b>1925002</b>
Air pressure with spring return		<b>1921 103</b>	<b>1923003</b>	<b>1925003</b>
<b>Accessories</b> Screw plug G 1/4		<b>3610264</b>	<b>3610264</b>	<b>3610264</b>
O-ring 10x2		<b>3000347</b>	<b>3000347</b>	<b>3000347</b>
Spare seal ring		<b>3000536</b>	<b>3000536</b>	<b>3000536</b>
Contact bolt, dome head (see G 3.800)		<b>3614002</b>	<b>3614028</b>	<b>3614003</b>